

MULE-HIDE PVC T-JOINT COVER

PRODUCT DESCRIPTION

PVC T-Joint Covers are made from 40-mil non-reinforced flashing cut into a 4.5" diameter circle.

BASIC USES

PVC T-Joint Covers are used to seal step-offs at splice intersections. Installation is mandatory on all 80-mil PVC systems and on 50-mil and 60-mil systems where step-offs have not been properly sealed.

TYPICAL PROPERTIES

Size:	4.5" (114 mm)
Thickness:	0.040"
Packaging:	100 per box
Weight (per box):	3.5 lbs. (1.6 kg)
Material:	Non-reinforced PVC Flashing
Color:	White, Tan, Gray

PACKAGING AND STORAGE

PVC T-Joints should be stored in a clean, dry area and protected from extreme temperatures. On the job site, store the PVC T-Joint Covers in a cool, shaded area and cover with light-colored, breathable, waterproof tarps.

PRECAUTIONS

1. PVC T-Joint Covers that have been exposed to the weather for 7 days or longer prior to use must be prepared with PVC Membrane Cleaner before hot air welding.
2. The PVC T-Joint Cover is not intended for use to overlay fasteners and plates. This requires the use of reinforced membrane.

INSTALLATION INSTRUCTIONS

1. Clean seam intersection area with PVC Membrane Cleaner.
2. Use a lower temperature setting on the heat welder than compared to welding reinforced membrane. (Typically a setting of "6" on a scale of "10" is appropriate for welding PVC T-Joint Covers.)
3. Center the T-Joint Cover over the seam intersection, begin welding at the center point and work towards the outside. Use the edge of the roller to crease the T-Joint Cover into membrane step-offs to achieve a proper seal.
4. Using a probe, check all seams for voids and cold-welds. Make any needed repairs.

TECHNICAL SERVICES

Contact Mule-Hide Products Co., Inc. at 608/365-3111 for additional information.

DISCLAIMER

The statements provided concerning the material shown are intended as a guide for material usage and are believed to be true and accurate. No statement made by anyone may supersede this information, except when done in writing by Mule-Hide Products Co., Inc. Since the manner of use is beyond our control, Mule-Hide does not make nor does it authorize anyone to make any warranty of merchantability or fitness for any particular purpose or any other warranty, guarantee or representation, expressed or implied, concerning this material except that it conforms to Mule-Hide's physical properties. Buyer and user accept the product under these conditions and assume the risk of any failure, any injury of person or property (including that of the user), loss or liability resulting from the handling, storage or use of the product whether or not it is handled, stored or used in accordance with the directions or specifications. Mule-Hide must be notified in writing of any claims and be given the opportunity to inspect the complaint or failure before repairs are made.

MULE-HIDE PRODUCTS CO., INC.

P.O. Box 1057, Beloit, WI 53512-1057 • 608/365-3111 • Fax: 608/365-7852 • www.mulehide.com